



PRODUCT NAME : High Brightness Green
Electroluminescent (EL) Wire
- 2.5 meters - High brightness,
long life

PRICE : Rs 1,799.00
SKU : RM3453



DESCRIPTION

EL Wire, also known as Electroluminescent wire is a stiff wire core coated with phosphor and then covered with a protective PVC sheath. When an AC signal is applied to it, it glows an aqua (blue green) color. You can make it look different colors by changing the coating, for example this is a vivid lime green. It looks a little like thin neon. Very bendable, it keeps its shape and you can curl it around your finger. Its an easy way to add some glow to a project, not as bright as LEDs but uses a lot less power!

We've got 2.6mm thickness EL wire, with a lime green coat, pre-cut and soldered to a standard quick-connect EL wire. It is made with the latest technology and twice as bright as 'standard' 2.3mm EL - running it at 1.5KHz/90V it emits 123 cd/m² or light and a half-life (50% brightness reduction) after 3000 hours of continuous use. Draws about 10mA per meter. The capacitance is about twice that of 'standard' EL, 11 nF/m so if you're using an inverter, it will drive only half as much high brightness wire as standard.

Often used for costuming, decoration, accent lighting, safety vests, bicycle/motorcycle/car/boat/home decoration, signs, etc! This wire is not designed explicitly for outdoor use so it will fade if continuously exposed to UV.

To use, the wire must be connected to an inverter that provides an AC supply of approximately 100V at 2000 Hz. An inverter is not included! This wire is 250 cm long which is the maximum that can be driven [by our handy 2xAA portable pocket inverter](#) The full length draws 200mA from the 2xAA batteries (so 2000mAh batteries will last ~10 hours if on 'constant' mode)

[We used EL wire to make our awesome TRON bag](#) so check it out for ideas

This is a pre-cut, pre-soldered, 250 cm long piece of EL You can plug this right into an inverter and get glowing in seconds, and if you want to do something a little more complex, cut and resolder it as desired. Soldering to EL wire is a little tricky but luckily [we wrote a detailed step-by-step tutorial!](#) To cut and re-solder EL, you'll need [wire strippers](#), a [soldering iron](#) & [solder](#), copper tape and heat shrink. A [third-hand tool](#) is really useful as well